

INSTALLATION INSTRUCTION

LED CEILING DOME LIGHT

LED Chip: AC220 – 240V, 50/60 Hz



!WARNING

- Turn off the power before inspection, installation or removal.
- Please do not exceed the rated voltage or wattage.

INTRODUCTION

Thank you for selecting and buying V-TAC LED Daylight Sensor. V-TAC will serve you the best. Please read these instructions carefully before starting the installation and keep this manual handy for future reference. If you have any other query, please contact our dealer or local vendor from whom you have purchased the product. They are trained and ready to serve you at the best.

PRODUCT FEATURES

- This ceiling lighting fixture is with LED diode, which has technology advantage, energy savings, and environmental protection, long life span, saving electricity cost and almost no maintenance time and cost needed.
- It has 100% efficiency and brighter than any other old fixtures.
- No maintenance, easy to install, high efficiency, low electricity, power saving, long life span, low temperature.

NOTES

- Lighting installation should not be covered. Leave some spaced around the fixture for ventilation.
- Risk of shock, hence disconnect at fuse or circuit breaker before installation or servicing.
- Risk of fire, supply conductors (power wires) connecting fixture must be rated minimum 90°C. If uncertain, consult electrician.

WARRANTY

- This product is warranted from manufacturing defect only.
- The warranty is valid for 2 years from the date of purchase.
- The warranty does not apply to damage caused by incorrect installation or abnormal wear and tear.
- The company gives no warranty against damage to any surface due to incorrect removal and installation of the product.

WARNING

- NOTE: Although easy to fit, this lamp requires wiring to the main and for safety should only be fitted by a qualified electrician.
- Having issued this warning, the company accepts no responsibility for issues arising for any failures to comply with these clear instructions.
- The company will not accept any responsibility for any other issues arising from improper use of fitting of this product as these matters are beyond our control.

INSTALLATION INSTRUCTIONS

! WARNING

- Install only by certified electrician.
- **The light works on AC 220 – 240V.**
- Proper grounding should be ensured throughout installation.
- The lighting should be located in dry areas.

