Typical base as below:



# 4 Channel 0-10V Touch Glass Panel Dimmer

Model No.: T18-1

4 zone/Touch glass panel/Brightness slide/Wireless remote control





Features C€ RoHS @mc LVD

- Touch panel 0-10V dimmer, output 4 channel 0-10V signal.
- Output connect with 0/1-10V dimmable driver.
- Ultra sensitive high strength glass touch panel with touch slide in the middle.
- Compatibility with RF 2.4G dimming remote control.
- Touch keys with LED indicator.
- White & Black glass panel available.


# Technical Parameters

Input and Output	
Input voltage	AC100-240V
Output signal	0-10V (20mA)
Output current	20mA/CH
Environment	
Operation temperature	Ta: -30°C ~ +55°C
Case temperature (Max.)	Tc:+65°C
IP rating	IP20
Warranty	
Warranty	5 years


Safety and EMC	
EMC standard (EMC)	ETSI EN 301 489-1 V2.2.3 ETSI EN 301 489-17 V3.2.4
Safety standard(LVD)	EN 62368-1:2020+A11:2020
Radio Equipment(RED)	ETSI EN 300 328 V2.2.2
Certification	CE,EMC,IVD,RED

Dimming data	
Input signal	Touch key + RF 2.4GHz
RF Control distance	10m(Barrier-free space)
Dimming level	256 levels
Dimming range	O - 1 OO%

## Mechanical Structures and Installations



### Installation diagram:



# Key function




Note: The default output is 0-10V, if you want to 1-10V output, please touch power key to turn off light, then long press power key for 15s immediately, the output will become 1-10V.

Touch power key to turn off light, then long press power key for 10s immediately, the output will return 0-10V.

User Manual Ver 1.1.2

# Wiring diagram



Note: We recommend the number of LED drivers connected to 0/1-10V dimmer (each channel) does not exceed 50 pieces, The maximum length of the wires from dimmer to LED driver should be no more than 50 meters.

# Match Remote Control (two match ways)

The O-10V touch panel dimmer can also match with the RF 4 zone dimming remote (optional). End user can choose the suitable match/delete ways. Two options are offered for selection:

### Use On/Off key

### Match:

Turn on light, turn off, immediately press the On/Off key of the panel for 5s,

then press any zone key of the RF remote within 5s. The LED indicator fast flash 3 times means match is successful.

#### Delete.

Turn on light, turn off, immediately press the On/Off key of the panel for 10sto delete all match, The LED indicator fast flash 6 times means all matched remates were deleted

### Use Power Restart


### Match:

Switch off the power, then switch on power, repeat again, Immediately short press any zone key 3 times on the remote. The light blinks 3 times means match is successful.

### Delete:

Switch off the power, then switch on power, repeat again, Immediately short press any zone key 5 times on the remote. The light blinks 5 times means all matched remotes were deleted

# Dimming curve




#### Nloto:

When the output channel is off, the output dimming signal is OV.

Please read the dimming section of the 0/1-10V dimming driver manual.

If the dimming characteristic curve is the same as below,

it will not be able to turn off the lights, you need select other models of 1-10V dimmer which have AC OUT function.



User Manual Ver 1.1.2